

1234 Kingsway
Vancouver, B.C.
V5V 3E1



tel (604) 875-9722
fax (604) 875-1480
www.midlandcanopies.com

Instructions for Deluxe Canopies

1. Assemble roof structure first. Use a mallet to hammer all poles fully into fittings. This is important so that the roof fits properly. On our regular canopies, use tape to hold the poles in the fittings. On our HD Canopies, tighten the eyebolts when pole is fully inserted.
2. If you have purchased Snowload Kits, (Instructions are separate) they should be installed at this point. Make certain that there are no rough edges that will touch the rooftop. Roof Braces can also be installed at this time.
3. Put Valance roof on structure attaching the corner ties first, place all ball bungees alternating one side and then the other. The ends of the valance rooftop with rope in them go on the peaked end of the frame. The roof must be firmly secured. If required, wrap Ball Bungee around poles twice. From time to time we suggest that you re-tighten the roof.
4. Insert legs one side at a time. This will require more than one person. It is easier to install footpads before the leg poles are put on canopy.
5. Side panels and end panels should be installed using Ball bungees.
6. We recommend that you attach your footpads to treated 2 x 6 boards along each side.
7. We **STRONGLY RECOMMEND** that you anchor your canopy to the ground. We suggest a minimum of one tie strap per every leg on your canopy.
8. Call us if you have any questions.

We do not guarantee our canopies against snow or wind. Snow should be removed.